

RobotAnno_602 robot arm manual

Anuo Robot (Shenzhen) Co., Ltd.

February 20, 2020

This manual is the operating instructions for users of RobotAnno 602.
Last revision date: February 2020

For sales and technical support, please contact Anuo Robot (Shenzhen) Co., Ltd.

E-mail: sales@robotanno.com

Commend

respected user:

Thank you for purchasing and using RobotAnno products. For your safety and benefit, please read this product user manual and all the accompanying materials carefully before using the product. If you fail to operate and use the product according to the user manual, any Anno Robotics (Shenzhen) Co., Ltd. will not be liable for any personal injury, property, or other loss.

About this product user manual (hereinafter referred to as "manual")

- The copyright of this manual belongs to Anuo Robot (Shenzhen) Co., Ltd. ;
- The trademarks and sizes mentioned in this manual belong to their respective rights holders;
- The contents of the manual are the same as the actual product, and the actual product shall prevail.

If you have any questions or objections to the contents or terms of the manual, please submit a written objection to Anno Robotics (Shenzhen) Co., Ltd. within seven days after purchasing the machine, otherwise you are deemed to have agreed, understood and accepted the entire content of this manual.

During the use of the product, if you encounter problems, please call us: +86 0755-36950696.

Anuo Robot (Shenzhen) Co., Ltd. reserves the right to explain and modify the user manual. The amendment, update and explanation of the manual will be on the RobotAnno website (<http://www.robotanno.com/>) To announce, so stay tuned.

Thanks!

Anuo Robot (Shenzhen) Co., Ltd.
2020

Anuo Robot (Shenzhen) Co., Ltd.

Address: 705, Building 1, Nanchang First Industrial Zone, Guzhen Community, Xixiang, Baoan District, Shenzhen

Phone: +86 0755-36950696

Email: robotanno@robotanno.com

After-sales email: support@robotanno.com



- This manual provides a comprehensive description of the use of the RobotAnno602 robotic arm. Be sure to operate the robotic arm after careful reading and full understanding.

Official Website: www.robotanno.com

RobotAnno Desk Robotic Arm
5F,Buliding F,SIAT,1068 Xueyuan Av, Nanshan,SZ
Tel: +86 0755-36950696
E-mail: robotanno@robotanno.com
After-sales service: support@robotanno.com
Internet Website: <http://www.robotanno.com/>



- The drawings and photos in the manual are representative examples and may differ from the product purchased.
- The manual is sometimes modified due to product improvements, specifications changes, and the manual itself is easier to use. The revised manual will be updated with the version number under the

cover and issued as a revised version.

- If you need to order the manual due to damage, loss, etc., please contact our sales department and order the cover version
- Customers make unauthorized product transformations, which are not covered by the company's warranty, and the company is not responsible.

目录

I. Safety precautions.....	3
2.Preparations:.....	10
3.Debug the robotic arm to a vertical position.....	11
4. Reset.....	17
5. Enter file mode.....	18
6. Adjust the speed.....	24
7. Clear operation.....	25
8.Check the current position of the robot arm.....	25
9. RobotannoV2.0 instructions.....	26
10. I / O and encoder hardware interface definition.....	32
11.602 parameters.....	38
12.Case.....	42
13.Function mode and programming.....	43

I. Safety precautions

Thank you for purchasing our RobotAnno robotic arm. For your safety and to prevent damage to the robotic arm, please read and master this manual and other auxiliary materials before using the RobotAnno robotic arm, and familiarize yourself with all the equipment knowledge, safety knowledge and precautions Get started

and pay special attention to the following safety signs.

Symbols and their meanings



危険

It is dangerous when mishandled, and death or



注意

It is dangerous when mishandled, and may cause moderate injuries, minor injuries, or damage to objects.



強制

Things to observe in manuals and



禁止

Things explicitly prohibited in manuals

Even matters that fall into the category of "Caution" can have serious consequences depending on the situation. Therefore, any "Caution" is extremely important and must be strictly observed.



Although it does not comply with the contents of "Caution" or "Danger", in order to ensure safe and effective operation, the matters that the user must also observe will be described in relevant places.

2. Dangerous matters



(1) In an emergency, press the emergency stop button immediately. If the mechanical arm cannot be braked in time, it may cause personal injury or equipment damage.



Emergency stop button

(2) When the servo power is turned on after the emergency stop is canceled, the emergency stop button must be canceled after the emergency stop caused the accident.



Emergency stop status released

(3) When moving within the motion range of the robot arm, please observe the following:

- 1) Consider the contingency plan when the robot arm suddenly moves to its prescribed position.
- 2) Make sure to set up shelters just in case.



Manipulator movement caused by misoperation may cause personal injury.

(4) When performing the following operations, please make sure that no one is within the action range of the robot arm and the operator is operating in a safe position:

- 1) When RobotAnno robot arm is powered on.
 - 2) When operating the robot arm with g code.
 - 3) During trial operation.
 - 4) During teaching and playback.
- (5) Please don't move and repair the robot arm while the robot arm is working. If you

want to move and repair, please turn off the power of the robot arm, and then perform this operation after power off.



Inadvertently entering the movement range of the robot arm or coming into contact with the robot arm may cause personal injury. If an abnormality is found, immediately press the emergency stop button.

The emergency stop button is located on the front right side of the RobotAnno602 robotic arm electrical control box.

3. Matters needing attention

(1) Before using RobotAnno robot arm, check the following items, if there is any abnormality, repair it in time or take other necessary measures.

- 1) Whether the electrical cables are properly connected;
- 2) Whether the sheath of electrical cables is damaged;
- 3) Whether the emergency stop switch is in the released state;
- 4) Are there any abnormal or abnormal sounds in the movement of the robot arm?

(2) The owner and operator of the RobotAnno robot arm must be responsible for their own safety. Anno Robot reminds users that they must wear safety protection equipment when using robot arm products and must abide by the safety provisions.

(3) Do not modify the robot arm

Please don't modify the robot arm, accidents or failures caused by unauthorized product modification are not covered by our warranty, and our company will not be responsible.

(4) Do not approach the robot arm in operation

Do not approach the moving robot arm to prevent accidental injury or damage to the robot arm.

(5) Please clearly designate the person responsible for supervision

In order to prevent operation errors during manual adjustment or accidents caused by insufficient safety confirmation, when two or more people operate, please clearly designate the person responsible for supervision.

(6) Use the robot arm on the basis of understanding the "Warning Signs" in the RobotAnno robot arm instruction manual.

4. Use environment

(1) Do not place the robot arm in a harsh environment. Dirt, waste, and high temperatures can damage internal components.

(2) After using the robot arm, unplug the power cord, and place the robot arm in a dry, normal temperature place. High temperature and harsh environments can damage the internal components of the robot arm.

(3) RobotAnno robot arm cannot be used in the following situations:

- 1) Environment close to flammable substances
- 2) Explosive environment
- 4) in water or other liquids
- 5) In an environment with corrosive and flammable gases
- 6) Environment with temperature exceeding 40 degrees Celsius
- 7) Other harsh environments

5. Safe operating procedures

(1) When controlling the movement of the robot arm

1) Before operating the robotic arm, it is necessary to adjust the movement of the robotic arm at a lower rate to increase the effective control of the robotic arm.

2) Consider the movement trend of the robot arm before pressing the power button.

3) It is necessary to consider the trajectory of the robot arm in advance and

confirm that the line is not interfered.

4) The area around the robot arm must be clean and free of oil, water and impurities.

(2) Production operation

1) Before starting and running, you must know all the tasks that the robot arm will perform according to the programmed program.

2) Know the position and status of all switches, sensors and control signals that will affect the movement of the robot arm.

3) You must know the location of the emergency stop buttons on the robotic arm control equipment and be prepared to press them in an emergency.

4) Never think that the robot arm has completed its program without moving, because the robot arm is most likely waiting for an input signal to let it continue moving.

6. Routine maintenance and storage

The RobotAnno robotic arm is safe to use and can adapt to the environment to the greatest extent. When using it, please follow the instructions in the manual. Be sure to follow the precautions in this manual.



(1) Never force the axis of the mechanical arm, otherwise it may cause personal injury and equipment damage.

(2) Avoid temperatures below 20 degrees Celsius or above 40 degrees Celsius;

(3) Avoid placing it in direct sunlight for a long time;

(4) Avoid being in dirt and dusty environment;

(5) Keep away from strong vibration environment;


(6) Keep away from high humidity environment;

(7) Keep away from static environment.

2.Preparations:

Positioning of the robot arm after unboxing


After unboxing, the position of the robot arm is as follows:




3. Debug the robotic arm to a vertical position

1. Install usb to rs232 driver

First connect the computer to the controller through a data cable, as shown in the figure:



Open the Annuo factory data package, open the USB TO RS232 folder, and selectively install it according to the computer system used. Here, take Win7 / Win7 system as an example.



File Explorer window showing the directory structure of the USB TO RS232 folder.

Address bar: F:\安诺出厂资料\USB TO RS232

Navigation pane (Left):

- 快速访问
- 桌面
- 下载
- 文档
- 图片
- OneDrive
- WPS网盘
- 此电脑
- 视频
- 图片
- 文档
- 下载
- 音乐
- 桌面
- Win 10 Pro x64 (C)
- 新加卷 (E:)
- 新加卷 (F:)
- 新加卷 (G:)
- 网络

Main pane (Right):

名称	修改日期	类型	大小
FTClean	2019/9/25 14:31	文件夹	
Linux_x86_64	2019/9/25 14:31	文件夹	
MAC	2019/9/25 14:31	文件夹	
win98_me	2019/9/25 14:31	文件夹	
win2000_xp_vista_x86_x64	2019/9/25 14:31	文件夹	
Wince	2019/9/25 14:31	文件夹	
windows 7.0	2019/11/15 19:47	文件夹	
Windows Server 2003_2008_x86_x64	2019/9/25 14:31	文件夹	

File Explorer window showing the contents of the windows 7.0 folder.



Address bar: F:\安诺出厂资料\USB TO RS232\windows 7.0


Navigation pane (Left):

- 快速访问
- 桌面
- 下载
- 文档
- 图片
- OneDrive
- WPS网盘
- 此电脑
- 视频
- 图片
- 文档
- 下载
- 音乐
- 桌面
- Win 10 Pro x64 (C)
- 新加卷 (E:)
- 新加卷 (F:)
- 新加卷 (G:)
- 网络

Main pane (Right):


名称	修改日期	类型	大小
CDM 2 06 00 Release Info	2012/5/9 15:36	RTF 文件	102 KB
Setup	2012/5/9 15:36	应用程序	2,291 KB
Setup	2019/11/15 19:47	WinRAR 压缩文...	1,719 KB






When you see the USB Serial Converter in the universal serial bus controller, the USB TO RS232 driver is successfully installed.


Select the port just installed. The port number of each machine may be different. The actual port will prevail.




Select the correct serial port number, and then click the [Serial Port Not Open] button as shown in the figure below




2. Enter debug mode



Click the button shown in the figure above, [Pause 30h], [Exit 10h], [Debug 14h], and then click the teaching above.




As shown in the above figure, adjust the 1 ~ 6 joints, and adjust the robotic arm to the vertical state as shown in the right figure below. The lower left figure is the robot arm joint + -direction pattern.




4. Reset

Click [Pause 30h], [Exit 10h], and [Reset 12h] in order to reset. The following figure shows the position after reset.




Note: Reset is that each axis moves in one direction in order to make the induction switch touch the induction screw. If the induction switch is already behind the induction screw before resetting, the axis will reach the limit position. Press the emergency stop button. For details, see 602 Reset video.

5. Enter file mode



As shown in the figure above, click the buttons [Pause 30h], [Exit 10h], [File 11h] to enter the file mode.

Read file



After selecting the [File] tab, click the [Read] button, and then select the [Editing area] tab to copy the following file contents to the editing area:

```
FILE=ST
AM.ST
216
code:
G00 J1=0 J2=0 J3=-90 J4=0 J5=-90 J6=0
G20 X=217.4 Y=0 Z=431.1 A=0 B=180 C=0 D=0
G20 X=300 Y=0 Z=285 A=0 B=180 C=0 D=0
G20 X=400
G20 Y=100
G20 X=300
G20 Y=0
G20 X=217.4 Y=0 Z=431.1 A=0 B=180 C=0 D=0
```

The above file content realizes a continuous action of a square trajectory.

file = st indicates the file type

am.st represents the name of the file

216 indicates the number of bytes in the file


code: the following sections are run instructions

```
FILE=ST
AM.ST
216
code:
```

This part is the file header. Every executable file is like this. 216 bytes can be filled with a number first. After downloading, the controller will calculate a correct number of bytes to fill.

G00 j1 = 0 j2 = 0 j3 = -90 j4 = 0 j5 = -90 j6 = 0 indicates the coordinate of the walking joint of the robot arm.

G20 X = 217.4 Y = 0 Z = 431.1 A = 0 B = 180 C = 0 D = 0 means that the manipulator moves in rectangular coordinates, the following is the explanation of (x, y, z, a, b, c, d)



===== Six-axis robot Cartesian coordinate system =====

$P(x, y, z, a, b, c, d)$

x: X-axis distance (P-point X-axis component);

y: Y-axis distance (P-point Y-axis component);

z: Z-axis distance (P-point Z-axis component);

a: attitude plane angle;

The angle a is the angle between the vector of the attitude vector PQ mapped in the XOY plane and the OX axis;

Angle range: $(-180, 180)$;

b: attitude line face angle;

The angle b is the angle between the attitude vector PQ and the OZ axis;

Angle range: $(0, 180)$;

c: attitude rotation angle;

The c angle is the angle between the vector mapped by the tool vector in the XOY plane and the OX axis;

Angle range: $(-360, 360)$;

d: angular state of each joint in the model;

d is an integer, no value is 0 by default;


Provisions:

0: The end mapping is in the positive direction, the same direction as d1 of the dh parameter, the third axis angle (-) sign, and the fifth axis angle (-) sign;

1: The end map is in the positive direction, the same direction as d1 of the dh parameter, the third axis angle (-) sign, and the fifth axis angle (+) sign;


- 2: The end map is in the positive direction, the same direction as d1 of the dh parameter, the third axis angle (+) sign, and the fifth axis angle (-) sign;
- 3: The end mapping is in the positive direction, the same direction as d1 of the dh parameter, the third axis angle (+) sign, and the fifth axis angle (+) sign;
- 4: The end mapping is in the negative direction, inverse to d1 of the dh parameter, the third axis angle (-) sign, and the fifth axis angle (-) sign;
- 5: The end mapping is in the negative direction, inverse to d1 of the dh parameter, the third axis angle (-) sign, and the fifth axis angle (+) sign;
- 6: The end is mapped in the negative direction, inverse to d1 of the dh parameter, the third axis angle (+) sign, and the fifth axis angle (-) sign;
- 7: The end is mapped in the negative direction, inverse to d1 of the dh parameter, the third axis angle (+) sign, and the fifth axis angle (+) sign;

2. Download the file to the controller



As shown in the figure above, click the [Download] button, and a prompt of successful download will be displayed in the position shown in the editing area.


3. Run the file



As shown in the figure above, click the buttons [Pause 30h], [Exit 10h], and [Run 13h] in order to see the movement of the robot arm.


For file operation, the robot arm will continue to move and will not stop automatically.

4. Stop file running




As shown in the figure above, when the file is running, if the robot arm is always moving, and you need to stop the movement, click the [Stop] button, the robot arm can stop the movement.

5. Resume file movement



As shown in the figure above, after stopping the file movement, if you need to continue the file movement that was stopped before, then click the [Run] button and you can see that the robotic arm continues to move at the position where it stopped before.

6. The robotic arm returns to the zero position




As shown in the figure above, if the robot arm needs to return to the zero position (vertical

position), click [Pause]-> [Exit]-> [Return to Zero], and the robot arm will move to the vertical position.

After clicking the above three buttons in turn, if the robot arm does not move, click these three buttons in turn.

6. Adjust the speed




As shown above, the row of buttons can adjust the speed of the robot arm movement.

note:


- 1) If you press the speed adjustment button while the file is moving, it will run at the speed you set in subsequent movements.
- 2) Before executing a single instruction, if the speed adjustment button is pressed, the next movement instructions will move at the speed you set.
- 2) In the motion command, the g code command used to control the speed is g07 vp = ## (0 ~ 100), for example: g07 vp = 50, which means that the speed is adjusted to fifty.

7. Clear operation



As shown in the figure above, if there are more data in the [Receive Area], you can press the [Clear Receive] and [Clear Edit] buttons to clear the data in the Receive Area.

8. Check the current position of the robot arm



As shown in FIG:

Check the position of the joint rotation angle of the robotic arm, click [Joint Output], and then click [Pause 30h]. In the [Receiving Area], you can see the rotation angle of each joint.

Check the space coordinate position of the robot arm, click [Coordinate Output], and then click [Pause 30h], and you can see the position of the space coordinate in the [Receiving Area].

9. RobotannoV2.0 instructions

1 When the computer opens the robotanno2.0 software for the first time, and the serial port is connected, a prompt window will pop up and a folder will be automatically created in the root directory of the current software disk of robotanno2.0



Chosse ok




Choose ok again, and then restart the software.




When the serial port is connected, the port number will be displayed automatically. If the serial port cannot be connected, the port number will be blank. If the serial port is not connected, you need to check the serial port connection




2 Open the software interface




Click Restart, the beige receiving area will receive the system version information



3 Enter reset mode, click pause, exit, reset




The stepper motor finds the origin sensor and resets it. Before operation, the parameter file of the controller is required.




The servo motor reads the absolute encoder position. Before operation, the parameter file of the controller is required, and the zero return file is configured correctly.

4 Enter teaching mode, click pause (30H), exit (10H), teaching (14H)

Click Pause, the receiving area receives the current position of the robot (joint position or rectangular coordinate position). When you click the joint to print, press Pause again, the joint angle is printed, and the joint debugging controls (J1 +, J1-, J2 +, J2-, J3 +, J3-, J4 +, J4-, J5 +, J5-, J6 +, J6-,) The brackets in the control are 1234567890- = on the keyboard after selecting the keyboard.



When you click rectangular printing, press Refresh to print the rectangular coordinate position and posture, you can operate the joint debugging controls (x +, x-, y +, y-, z +, z-, a +, a-, b +, b-, c +, c-,) Control brackets are corresponding to the selected keyboard after ticking



Robot Anno

This area is the receiving area

This area is the editing area

language

Clean Edition

Clear Receive

Restart

Init Pos Teach

Run File

Exit Reset

Speed+ 35

Speed- Update

Stop/30H

Send

Speed 100% Speed 75% Speed 50% Speed 20% Speed 5%

F1:EXIT F2:INITIAL F3:RUN F4:STOP

File,reset,run,teach,initial mode must be paused and then exited before entering

Enter Query Servo On Soft Limit On Port Alarm On

Output Query Servo Off Soft Limit Off Port Alarm Off

Homepage | Side Page | **Projects** | **Debug** | IO Port

<Tips>

1. save the file before downloading

2. Confirm the file processing mode before download

Save while downloading

Open Save Multiple File Formats

Run Read Download Run File Header

Reset Read Reset File Header

Param Read Parameter Download Parameter File header


Multiple file formats: FILE=T_1
FILE=T_2... FILE=T_124

620 X=217.4 Y=0 Z=431.1 A=0 B=180 C=0 D=0


The screenshot displays the Robot Anno software interface, which is used for controlling a robot. The interface is divided into several sections:

- Top Left (Code Editor):** Displays a G-code program. The first line is highlighted in red: `G54.755 Y=-101 Z=414.2382 A=0 B=176.8076 C=0.0369 D=1`. The program includes various G-code commands for positioning and tool changes.
- Top Right (Language Selection):** A dropdown menu labeled "Language" is visible.
- Bottom Left (Control Panel):** Contains buttons for "F1:EXIT F2:INITIAL F3:RUN F4:STOP", "File.reset.run.teach.initial mode must be paused and then exited before entering", and a speed control section with buttons for "Speed+", "Speed-", "Speed 100%", "Speed 75%", "Speed 50%", "Speed 20%", "Speed 5%", and a "Stop/30H" button.
- Bottom Center (Status Bar):** Shows the current coordinates: `G20 X=217.4 Y=0 Z=431.1 A=0 B=180 C=0 D=0`.
- Bottom Right (Coordinate Table):** A table with columns for Joint, Angle, and a text area. The table contains data for joints 1 through 8, including coordinates and angles. The text area contains the instruction: "Angle teaching needs to select Angle print Get coordinate position after clicking pause".

6 File download, click pause, exit, file, download; (the download control needs to enter the correct password, the initial password is 1101)



7 Run, click pause, exit, run




10. I / O and encoder hardware interface definition

602_db9 interface definition		
Pin number	definition	Note
1	j1 return to zero switch signal line	
2	j2 return to zero switch signal line	
3	j3 return to zero switch signal line	
4	j4 return to zero switch signal line	
5	j5 return to zero switch signal line	
6	j6 return to zero switch signal line	
7	24V+	
8	GND	Share`
9	36V+	
602_db25 interface definition		
Pin number	definition	Note
1	OUT0	
2	OUT1	
3	OUT2	
4	OUT3	
5	OUT4	
6	customize	
7	customize	
8	IN0	
9	IN1	
10	IN2	
11	IN3	
12	IN4	
13	customize	
14	customize	
15	customize	


16	customize	
17	customize	
18	customize	
19	customize	
20	customize	
21	customize	
22	customize	
23	0V	Relay use
24	24V	
25	5V	
GND	GND	

The io port of the robot cannot directly send signals. It needs to be switched by a relay. Generally, the relay in the control box has been connected.


1. Definition of main control port




2.Main control wiring diagram:



3.Wiring circuit diagram of the relay in the control box:




4. Physical diagram of the relay relay wiring in the control box (only one set of output is connected in the picture):



When multiple outputs are required, the positive pole is connected to pins 1 to 5 (controlled by o00 to o04 respectively), and the negative pole is connected to pin 23 (shared).

11.602 parameters

1. Size parameters



2.Motor, reduction ratio parameters

axis	Harmonic reduction ratio	Belt reduction ratio	Single-turn pulse value
First axis	50	1.5	8192
Second axis	100	1.5	8192
Third axis	50	1.4	8192
Fourth axis	50	1.2	8192
Fifth axis	50	1	8192
Sixth axis	/	5	25600

3. Controller parameters

FILE=INI // File path Parameter.ini //file name

661 // File length (count the number of bytes from the fourth line to the last carriage return line feed)

//// DH_PARAMETER: // DH parameter (unit: mm; h axis, d is distance)

_h0=340;

_d1=0.1;


_h2=260;

_d3=25;

_h4=280;

_h5=72;

_d6=1;



//// motor_dir: // Motor direction

_dir1=-1;


_dir2=1;

_dir3=1;

_dir4=-1;

_dir5=1;

_dir6=1




```
//// joint_pul: // Organization breakdown
```

```
_j1pul = 614400; // Drive breakdown: 8192 // Reduction ratio 75
_j2pul = 1228800; // Drive breakdown: 8192 // Reduction ratio 150
_j3pul = 573400; // Drive breakdown: 8192 // Reduction ratio 70
_j4pul = 491520; // Drive breakdown: 8192 // Reduction ratio 60
_j5pul = 409600; // Drive breakdown: 8192 // Reduction ratio 50
_j6pul = 128000; // Drive breakdown: 25600 // Reduction ratio 5
////VELOCITY:      // speed setting
```

Note: mechanism breakdown = driver breakdown * structure reduction ratio

Example: The reduction ratio is 1: 100. The driver is subdivided into 8192 pulses / second. The mechanism is subdivided into $100 * 8192 = 819200$ pulses / second.

```
_ac=60000.0;      // Acceleration (increase in pulses per second)
_de=60000.0;      // Deceleration (reduction in pulses per second)
_vpp = 100000.0; // Highest speed (pulses per second)
_vp=10;           // Rate (Running speed  $ve = vpp * vp / 100$ ,  $ve$ : The current running speed of the device.)
////MODE:
_pve=8.887
_getCodeMode=1;   // 0 is teaching for joint output, 1 is teaching for right-angle output
_runCodeMode=1;   // 1 is the printing code, 0 is not printing the code
_prmTPUL=90;      // Pulse maximum width adjustment threshold (4 ~ 400) (v142)
_flagSoftRst=1
_brkMotorEn=0
_STACLR=0
_almLED=1
_iIRQ=0
_sIRQ=0           //Note
//REPOS           ///   Power-on motor default position (standby position)

_rePosJ1=1;
_rePosJ2=0;
_rePosJ3=-90;
_rePosJ4=0;
_rePosJ5=-90;
_rePosJ6=0;
_rePosJ6=0;
```

```
//LIMIT // Soft limit (0 in _sLp0 represents the axis number)

_sLp0=150 // Positive limit angle of the 1st axis software

_sLn0=-150 // 1st axis software negative limit angle
_sLp1=80
_sLn1=-80
_sLp2=0
_sLn2=-150
_sLp3=120
_sLn3=-120
_sLp4=85
_sLn4=-110
_sLp5=180
_sLn5=-180
```

12.Case

Suction handling case:

file = st // file type

am.st // File name

771 // bytes

code: // Run instruction

g07 vp = 50 // speed

G20 X=300 Y=131 Z=55 A=0 B=180 C=0 D=0

g06 o = p0.1 // open the nozzle

G20 X=300 Y=131 Z=47.5 A=0 B=180 C=0 D=0

G20 X=300 Y=131 Z=60 A=0 B=180 C=0 D=0

G20 X=300 Y=42.5 Z=60 A=0 B=180 C=0 D=0

G20 X=300 Y=42.5 Z=20 A=0 B=180 C=0 D=0

g06 o = p0.0 // Close the nozzle

g06 t = 1000 // wait one second

G20 X=300 Y=42.5 Z=47 A=0 B=180 C=0 D=0

G20 X=300 Y=131 Z=47 A=0 B=180 C=0 D=0

G06 O=P0.1

G20 X=300 Y=131 Z=38 A=0 B=180 C=0 D=0

G20 X=300 Y=131 Z=51 A=0 B=180 C=0 D=0

G20 X=300 Y=-46 Z=51 A=0 B=180 C=0 D=0

G20 X=300 Y=-46 Z=20 A=0 B=180 C=0 D=0

G06 O=P0.0

G06 T=1000

G20 X=300 Y=-46 Z=38 A=0 B=180 C=0 D=0

G20 X=300 Y=131 Z=38 A=0 B=180 C=0 D=0

G20 X=300 Y=131 Z=29 A=0 B=180 C=0 D=0

G06 O=P0.1

G20 X=300 Y=131 Z=42 A=0 B=180 C=0 D=0

G20 X=300 Y=-134 Z=42 A=0 B=180 C=0 D=0

G20 X=298 Y=-134 Z=22 A=0 B=180 C=0 D=0


G06 O=P0.0

G06 T=1000

G20 X=300 Y=-134 Z=42 A=0 B=180 C=0 D=0

13.Function mode and programming

File classification



Programming rules

Instruction writing:

1.Constant names: #xx.// xx specific values. Example: # 2, # 1000, # 5.

2.Variable name: vxx.//xx controller general-purpose storage unit. Example: v150 // V150.

3.Instruction rules: function instruction + space + operation instruction. Example:

```
g06 t = 200 // Delay 200 ms.
g07 ve = 2000 // Set the speed to 2000 pulses per second.g08 sto // The program
automatically pauses
```

4.Position command: Function command (g code) + space + position information Example: g20 x

```
= 270 y = 0 z = 300 a = 0 b = 180 c = 0 d = 0 // fixed
```

point

```
G21 X=270 Y=0 Z=300 A=0 B=180 C=0 D=0 // Go straight
```

```
g00 j1 = 20 j2 = 70 j3 = 2 j4 = 0 j5 = 7 j6 = 0 // joint
```

coordinates

5.Call instruction: g08 + space + acall + subroutine name

Example: g08 acall zaina

6.Jump instruction: g08 + space + ajmp + subroutine name

Example: g08 ajmp xxx // Jump to program xxx for execution.

7.Judgment instruction: g08 + space + if + judgment condition + statement a true: execute

statement a false: skip statement a and execute next.

Determine characters (<,>, ==,! =, <=,> =. Less than, greater than, equal to, not equal to, less than or equal to, greater than or equal to).

Example: g08 if # 2 <# 0 acall xxx

```
G08 IF #2>#0 ACALL XXX G08 IF #2==#0 ACALL XXX G08 IF #2<=#0
```

```
ACALL XXX G08 IF #2>=#0 ACALL XXX
```

8.Cycle instruction: for (assignment statement, judgment statement, statement B)

{Program segment}

Example: for (V0 = 2, V0 <V1, V0 = V0 + 3) {block

9, subroutine program writing:

g08 + space + subroutine program name + English colon // subroutine start

---- Program content

g08 + space + end // Subroutine end flag.

Subroutine naming rules: uppercase and lowercase letters, numbers.

Note: "/", *, +, -, %, // (division, multiplication, addition, subtraction, remainder, comment)" monocular operation has no priority.

3.Instruction list:

Position command	
Fixed point	g00 j1 = 0 j2 = 0 j3 = 0 j4 = 0 j5 = 0 j6 = 0 // joint coordinates.
	g20 x = 270 y = 0 z = 300 a = 0 b = 180 c = 0 d = 0 // Cartesian coordinates.
straigh ht line	g01 j1 = 10 j2 = 20 j3 = 40 j4 = 10 j5 = 2 j6 = 20 // Joint coordinates.
	g21 x = 300 y = 100 z = 500 a = 0 b = 180 c = 0 d = 0 // without acceleration / deceleration
	g41 x = 300 y = 100 z = 500 a = 0 b = 180 c = 0 d = 0 // with acceleration and deceleration
Arc	<p>Current point: g21 x = 200 y = 0 z = 200 a = -180 b = 150 c = 0 d = 0</p> <p>Second point: g22 x = 300 y = 100 z = 200 a = -180 b = 150 c = 90 d = 0 third point: g23 x = 400 y = 0 z = 200 a = -180 b = 150 c = 300 d = 0 arc operation: g06 degree = 300 or g06 degree = arc</p> <p>Note: g06 degree = radian.</p> <p>g06 degree = arc Three-point arc.</p>

G06		G07		G08	
instr	Features	instruct	Features	instructi	Features
T=XX	Delay xx milliseconds.	VE=XX	Speed is xx pulses	XXXX:	Subroutine name (English colon)
I=PA. 1	Wait for port a to be high. 1 is high and 0 is low.	AC=XX	Acceleration is xx pulses per second squared	ACALL XXXX	Call xxxx tags to g08 END
O=PA .0	a port outputs high level. 1 is high and 0 is low.	DE=XX	Deceleration is xx pulses per square	END	End of call
I=STA O	Wait for sta button low	VPP=XX	Maximum speed xx pulses per second	AJMP XXXX	Jump to xxx run
SCAN =I	Read the input port value. Return string "1111 1111 1111 1111 "	VP=XX	Speed ve is the highest speed XX%. $VE = VPP * VP * 0.01$	FLTAB=#	File jump to file t_# run;
SCAN =O	Read the output port value. Return string "0000 0000 0000 0000 "	_h0=xx	Height change	IFF	Floating point comparison
SCAN =RTC	Read the system clock value.	RCM=1	1 print run command, 0 not print Print run instruction	IF_ELSEF	Floating point comparison
DEGR EE=A RC	The robot walks a three-point arc.	GCM=1	1 Output in rectangular coordinates during teaching, 0 is output for joint coordinates	MOV VXX=#XX	Integer assignment.
DEGR EE=3 5	The robot walks 35.2 degrees.	Z-ADJ=xx	z-axis height adjustment	MOVF VXX=#XX	Integer assignment.
REPO S=J#	j # axis from the angle increase direction to find home # Sensor (back to low level)	UCS=FCS	Restore original coordinate system *	PRINT VXX	Print the value of vxx, integer formula.
REPO S=-J#	j # axis find home # from the angle decrease direction Sensor (back to low).	UCS=NO W	The center of the sixth shaft end flange For xoy *	PRINTF VXX ADD	Print the value of vxx, floating point formula Integer addition
REPO S=JH #	j # axis from the angle increase direction to find home # Sensor (back to high level)	ABSPOS	Update Cartesian Coordinate Data (xyz increment the amount)	INT VXX SUBB	Convert floating point to integer Integer subtraction
REPO S=-JH #	j # axis find home # from the angle decrease direction Sensor (back to high level)	P JH=XXXX	Calibration j # axis angle	FLOAT VXX STO	Convert integer to floating point Program pauses automatically
REPO S=Z#	j # axis to increase direction from angle to find z # + sense Reactor (back to low)	G07 MARKPOS_HERE X1=0 Y1=0 X2=100 y2 = 100 template mark point G07 MARKPOS X1=10 Y1=10 X2=110 y2 = 110 match mark point		NRST EXIT	Restart Exit run into idle mode

Notes:

g09 instruction function: communication with lower computer.

g09 copyright inquiry system yn

g09 com2 = xxxx com2 sends xxx characters

For example: g09 com2 = g00 j1 = 10 j2 = 10 j3 = -90 j4 = 0 j5 = 0 j6 = 0

This controller sends a command to another controller com1, g09

com2 10h serial port 2 sends 0x10

g09 com2 12h serial port 2 sends 0x12

g09 com2 13h serial port 2 issues 0x13 g09

com2 14h serial port 2 issues 0x14 g09 com2

15h serial port 2 issues 0x15 g09 com2 18h

serial port 2 issues 0x18

g09 enc It is a special instruction to connect with the absolute value servo motor, refer to the zero return file example;

4. Use of memory

Naming rules: VXX // xx units.

#XX //constant.

User arithmetic unit v0-v127, v400-v511

Port number type	The port	Software port number	regist er	Port number type	The port number	Software port number	regist er
input signal	i00	P0	v144	output signal	O00	P0	V160
	i01	P1	v145		O01	P1	v161
	i02	P2	v146		O02	P2	v162
	i03	P3	v147		O03	P3	v163
	i04	P4	v148		O04	P4	v164
	i05	P5	v149		O05	P5	v165
	i06	P6	v150		O06	P6	v166
	i07	P7	v151		O07	P7	v167
	i08	P8	v152		O08	P8	v168
	i09	P9	v153		O09	P9	v169
	i10	P10	v154		O10	P10	v170
	i11	P11	v155		O11	P11	v171
	i12	P12	v156		O12	P12	v172
	i13	P13	v157		O13	P13	v173
	i14	P14	v158		O14	P14	v174
	i15	P15	v159		O15	P15	v175
Note: The light on value is 0, and the light off value is 1.				Note: The light on value is 1, the light off value is 0			

Port number type	The port number	Software port number	registe r		Port number type	The port number	Software port number	registe r
Origin signal	HM0	P16	V192		Limit bit signal	LP0	P22	V198
	HM1	P17	V193			LP1	P23	V199
	HM2	P18	V194			LP2	P24	V200
	HM3	P19	V195			LP3	P25	V201
	HM4	P20	V196			LP4	P26	V202
	HM5	P21	V197			LP5	P27	V203
Servo alarm	ALM0	P28	V204					
	ALM1	P29	V205					
	ALM2	P30	V206					
	ALM3	P31	V207					
V256~V271: Value is 1 capture enable on, v189 = 0 students effect	ENi00	p0	V256		V288~V303: Capture duration value in millisecon ds, which needs to be cleared by software	FLAGi00	p0	V288
	ENi01	P1	V257			FLAGi01	P1	V289
	ENi02	P2	V258			FLAGi02	P2	V290
	ENi03	P3	V259			FLAGi03	P3	V291
	ENi04	P4	V260			FLAGi04	P4	V292
	ENi05	P5	V261			FLAGi05	P5	V293
	ENi06	P6	V262			FLAGi06	P6	V294
	ENi07	P7	V263			FLAGi07	P7	V295
	ENi08	P8	V264			FLAGi08	P8	V296
	ENi09	P9	V265			FLAGi09	P9	V297
	ENi10	P10	V266			FLAGi10	P10	V298
	ENi11	P11	V267			FLAGi11	P11	V299
	ENi12	P12	V268			FLAGi12	P12	V300
	ENi13	P13	V269			FLAGi13	P13	V301
	ENi14	P14	V270			FLAGi14	P14	V302
	ENi15	P15	V271			FLAGi15	P15	V303
Note: The light on value is 0, and the light off value is 1.								

Query input signal:

G06 SCAN=I // Scan port.

G08 IF v144==#0 ACALL XXX // If the i00 port signal is 0, call the program

xxx. or g06 i = p0.0 // Wait for i00 input.

G06 O=P0.1 // Make o00 output.

5. Model introduction

